

How to set up your sunshade free standing

- 2 Guide the battens through the small tubes of the sunshade and fix the tip in the centre part. Tension the batten and force the other tip in the pocket of the corner.
- 3 Assemble all four battens from centre part to corner pocket.
- 4 To adjust the pole in height, hold the outside tube and rotate the inside tube until it is loose. Pull out the inside tube to the desired height. Rotate the inside tube in the opposite direction until the pole is tightly fixed again.
- 5 Click in the pole.
- 6 Place the sunshade with pole and rubber foot.
- 7 Position the sunshade with 4 x rope to the railing.

