

How to install your wind catcher

- 1 Place the tip of the batten in the corner pocket.
- 2 Assemble both battens.
- 3 Place the crossed battens underneath the frame of the hatch opening.
- 4 Pull up the wind catcher with the halyard.
- 5 Place the mosquito net on deck.

